

Instruction Book

PURE F9



GB INSTRUCTION BOOK
FR NOTICE D'UTILISATION
AR دليل المستخدم
BG КНИЖКА С ИНСТРУКЦИИ
CZ NÁVOD K POUŽITÍ
DK VEJLEDNING
EE KASUTUSJUHEND

ES MANUAL DE INSTRUCCIONES
FA دفترچه راهنمای کاربر
FI OHJEKIRJA
HR UPUTE
HU HU HASZNÁLATI ÚTMUTATÓ
IT ISTRUZIONI
LT LIETOŠANAS PAMĀCĪBA

LV INSTRUKCIJŪ KNYGELĒ
NO BRUKSANVISNING
PL INSTRUKCJA OBSŁUGI
RO MANUAL DE INSTRUCȚIUNI
RU РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ
SE BRUKSANVISNING
SI NAVODILA ZA UPORABO

SK NÁVOD NA POUŽÍVANIE
SR УПУТСТВО
TR TALİMAT KİTAPÇIĞI
UA ІНСТРУКЦІЯ

VISIT OUR WEBSITE TO:



www.electrolux.com



Availability of Electrolux Webshop and Consumables & Accessories varies by region and country. Please refer to your local Electrolux website for more details or contact local customer service for support.

CONSUMABLES & ACCESSORIES



3in1 Nozzle
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Delicate brush
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Angled tube
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Filter 1
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Filter 2
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Filter 3
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Animal Delicate brush
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Bed Nozzle
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

Pet Nozzle
Ref: XXXxxx
Part nr: xxxxxxxx

missing image

PURE F9 Performance Kit
Ref: ESPK9
Part nr: 9001690784

missing image



Crispy Bamboo
Ref: ESBA
Part nr: 9001677773

Citrus Burst
Ref: ESMA
Part nr: 9001677807


Brown Sugar & Fig
Ref: ESFI
Part nr: 9001677781






Evening Rose
Ref: ESRO
Part nr: 9001677765

Tropical Breeze
Ref: ESCO
Part nr: 9001677799




S-fresh 18 Value pack
Ref: ESVP1
Part nr: 9001681221







⚙️ Certain models only


2





1






2





3

























4





5







7











8



9



⊕ Certain models only





Share more of our thinking at [electrolux.com](https://www.electrolux.com)

Electrolux Appliances AB
Sankt Göransgatan 143
SE 105 45 Stockholm
Sweden